HCM Series

- Module MPPT Wind Solar Hybrid Controller

User Manual



i

Contents

1. Important Safety Warning	1
2. Basic Information	1
2.1 Introduction and Features	1
2.2 Product Structure	2
3. Product Installation	3
3.1 Installation Notes	3
3.2 Installation and Wiring	3
3.2.1 Installation Steps	3
3.2.2 Electrical Connection	4
4. Operation Interface Introduction	6
4.1 LCD Display	6
4.2 LCD Information Define	7
5. Trouble Shooting 1	0
6. Technical Parameters 1	1
7. Warranty 1	3

1. Important Safety Warning

Before Using the controller, please read all instructions and cautionary markings on the unit and this manual. Save the manual where it can easily be accessed.

This manual includes all safety warnings, installation, and operation guidance of the HCM series wind&solar hybrid controllers.

- Before installing and using this controller, read all instructions and cautionary markings on the controller and all appropriate sections of this guide.
- Do not disassemble the machine, change the electrical components and parts yourself, or we will not responsible for the warranty items and related duties.
- To avoid a risk of fire and electric shock, make sure the existing wiring is in good condition and that the wire is connected tightly.
- Do not restart the controller immediately after it alarms. Please analyze the fault reasons and repair them at first, and then restart the controller until the fault is solved.

2. Basic Information

2.1 Introduction and Features

HCM series wind solar hybrid controller integrates the wind MPPT control, PV control and battery charge and discharge function in one machine.

Features:

- Recognize 12V/24V Battery automatically
- Wind turbine MPPT track point adjustable
- Electronic components in high quality
- Complete protection function
- > Solar and wind generation capacity and electricity consumption visible.
- Seven modes of load output optional.

- RS232/RS485/RJ45/GPRS/Bluetooth/Zigbee monitoring modes optional
- > Compatible with standard MODBUS communication protocol

2.2 Product Structure



Chart1. Product Overview

1	Battery terminal	6	Communication port
2	Wind turbine terminal		
3	PV terminal	(7)	M4 screw install hole
4	Load terminal	8	Dump load light
5	LCD Display	9	button

3. Product Installation

3.1 Installation Notes

- 1) The machine should be kept indoors and well ventilated;
- 2) Environment temperature: $-20 \sim +40$ °C; Humidity: <=95%, no condensing
- Altitude should not be more than 4000m. (>1000 m derating according to the GB/T3859.2 regulations)
- 4) Avoid using the machine in direct sunlight, sun exposure, rain, humidity, acid fog, and dust.
- 5) To guarantee the lifespan, it is suggested that the space around the device has no other items within 30CM.
- 6) The machine can only charge for the battery in the rated voltage range.
- 7) The machine can only be connected to the wind turbine and PV with allowed power and voltage.

3.2 Installation and Wiring

3.2.1 Installation Steps

Please refer to the specific installation situation. Generally speaking, if it is used in street light pole, you can fix the controller to the rail inside the light pole.

If it is installed in the power box, the power box is drilled according to the hole size, and the controller is fixed with M4 screw.



Chart 2: Installation Steps

3.2.2 Electrical Connection



Chart 3: System Overview

Please connect those parts according to the order of (1)(2)(3)(4), and notice the following items.

- 1. Connect the load positive and negative terminal to the "DC OUTPUT" terminals as"+""-1""-2" relatively. 2 output loads share the same "+" terminal.
- 2. Connect the battery bank to the controller by the terminal which marks "BATTERY". (do not reversed the connection of positive and negative terminals)
- When wind turbine is still or running in a low speed, connects its output cable to the "WIND INPUT" terminal on the controller.
- 4. Connected the terminals of solar panels to "SOLAR INPUT" terminals "+""-"on the controller;
- 5. Check all the connection to make sure they are connected rightly and tightly.

4. Operation Interface Introduction

4.1 LCD Display

After the power is connected, the whole screen is in a browsing status. It shows battery voltage, and can be changed to the following information by press related buttons.

Interface Introduction	Display interface	Display interface	Interface Introduction
Battery Voltage	BAT BAT BAT		Wind turbine voltage
Accumulative total electricity consumption			Wind turbine current
Accumulative total Solar generation capacity	└╷◯ः╼╗┣━ङ ┍ѵ В В.В.В ^{₩н}		Wind turbine power
Accumulative total wind turbine generation capacity			PV voltage

Light control off voltage	PV current
Light control on voltage	PV power
Load 2 Control off time	Load 1 current
Load 2 output mode	Load 2 current
Load 1 off time	Load 1 output mode

4.2 LCD Information Define

Name	Icon	Status
Wind Turbine	~	Rotate means wind turbine works normally
wind Turbine	BRAKE	Brake by hand
C - 1 - r	¢	Day
Solai	2	Night or PV is not connected

		Battery
Battery		Flickering meansover voltage
		Flickering means over -discharge
	-	Output normally
	Ŷ	No output.
Load	Ŷ	Flickering means overload
	5	Flickering means short circuit
		Light control on/off
		Light control on, time control off
7 load output control modes		Light control on, time control half power, light control off
		Light control on, time control half power, time control off

	Keep on
	Keep off
	Keep half power
Light control on/off voltage	Light control on voltage
	Light control off voltage
Time control time	Time control off time
	Time control half power time

Load		1st Load
		2nd Load
Power curve	上心 SET WIND 日日.日.日 ▲	Current at cut-in voltage or current at rated wind turbine voltage
	88:88	Parameters display
Others	"SET"	"SET" icon. When it appears, you can set related parameters by press the scan button.

5. Trouble Shooting

Fault Type	Description	Possible reasons and solutions	
	The connection between the battery and	Check the wiring and reconnect it	
No display	the controller is not tight	Check the wirning, and reconnect it.	
on LCD	LCD Battery is connected in wrong polarity Need change the internal f		
	to battery input terminals.	controller, and reconnect the battery.	
No charging	The connection cable between wind turbine and controller is loose.	Reconnect the cable tightly.	
	Wind turbine output voltage haven't reached the charging voltage,	Check whether the system voltage is reasonable.	

Wind turbine is in "Brake" statusThe connection cable between solar panel and controller is loose.The Solar panel is connected negatively to the controller.PV output voltage is not in accordance		Wind turbine is in "Brake" status	Press the button for 5s to release the brake status if it is manual brake. Wait the wind turbine recover automatically(about 10 mins) if it brakes for other reasons.
		The connection cable between solar panel and controller is loose.	Reconnect the cable tightly.
		The Solar panel is connected negatively to the controller.	Reconnect the cable.
		PV output voltage is not in accordance	Check the PV output and the system
		with the system voltage.	parameters.
		Load over load	Check if the load connection is normal. Remove the over load , press the set button on the load interface to recover output
No lo output	load	Load short circuit	Check the load, and press the set button on the load interface to recover output
		Battery undervoltage for the second time	Check if the battery icon on the LCD display flickers. If yes, it needs about 4 hours to recover automatically, or cut off the power and reconnect again.

6. Technical Parameters

Model	HCM400-12-12	
Wind Turbine Input		
Rated input power	400W	
Rated input voltage	12V	
Input voltage range	2~16V	
Rated input current	34A	
Manual Brake	Keep press the button for 5s to unload completely, and then recover by hand.	

Brake by over current	34A (factory default,0~40A settable) unload completely when reached the set current, and recover automatically after 10 mins.
Brake by overvoltage	Refer to "output overvoltage" control
PV Input	
Rated input power	200W
Max. Open circuit voltage	24V
Rated input current	17A
Reversed connection protection	YES
Charge Parameters	
Rated battery voltage	12V
Output overvoltage point	14V
Output overvoltage recovery point	12.7V
DC Load Output	
Output loops	2 loops
Output control mode	Both 2 loops could be set in 7 modes, such as light control on&off, light control on and time control off.
Output voltage range	10.8V~16V
Undervoltage recovery point	Refer to "rated battery voltage"
Rated output current	10A/each loop
Overload protection	120% rated DC output -1min,150% rated DC output -10s
Short circuit protection	Instant protection
General Parameters	
Rectifier mode	Uncontrolled rectifier
Display mode	LCD
Display information	Battery voltage, wind turbine voltage/current/ power, PV power/voltage/current, light control on voltage, light control off voltage, time control duration, load current, wind power generation capacity,

RS232 y: Battery voltage, wind turbine voltage/current/ power, ge/current, wind power generation capacity, solar power acity, Battery status, wind turbine status, day and night, overload, DC load short circuit, and so on. g: Output overvoltage point, wind turbine over current point, wind turbine start voltage, DC load ndervoltage/undervoltage recovery point, output mode
y: Battery voltage, wind turbine voltage/current/ power, ge/current, wind power generation capacity, solar power acity, Battery status, wind turbine status, day and night, overload, DC load short circuit, and so on. g: Output overvoltage point, wind turbine over current point, wind turbine start voltage, DC load indervoltage/undervoltage recovery point, output mode
g: Output overvoltage point, wind turbine over current point, wind turbine start voltage, DC load ndervoltage/undervoltage recovery point, output mode
loops,light control on voltage, light control off voltage, and wind turbine brake settings.
YES
<0.6W
-20°C ~+40°C
0~90% ,No condensing
≤65dB
Natural cooling
Wall-mounted
IP52
150×220×83mm

7. Warranty

The product shall be in warranty for one year from production. Please take contract as the final one if it has special terms on warranty.