

SmartShunt 500A / 1000A / 2000A

www.victronenergy.com



SmartShunt 500A



SmartShunt 1000A



SmartShunt 2000A



The SmartShunt is an all in one battery monitor, only without a display. Your phone acts as the display.

The SmartShunt connects via Bluetooth to the VictronConnect App on your phone (or tablet) and you can conveniently read out all monitored battery parameters, like state of charge, time to go, historical information and much more.


Alternatively, the SmartShunt can be connected and be read by a GX device. Connection to the SmartShunt is made via a VE.Direct cable.

The SmartShunt is a good alternative for a BMV battery monitor, especially for systems where battery monitoring is needed but less wiring and clutter is wanted.


The SmartShunt is equipped with Bluetooth, a VE.Direct port and a connection that can be used to monitor a second battery, for midpoint monitoring, or to connect a temperature sensor.

Differences compared to BMV712 Battery Monitor

- No programmable visual and audible alarm.
- No programmable relay.




Basic SmartShunt wiring





Connecting a SmartShunt to a GX device

500A / 1000A / 2000A
6,5 - 70 VDC
< 1mA
6,5 - 70 VDC
1 - 9999 Ah
-40 +50°C (-40 - 120°F)
Yes
-20 +50°C
Yes
UTION & ACCURACY
± 0,01A
± 0,01V
± 0,1 Ah
± 0,1%
± 1 min
± 1°C/°F
(0 - 50°C or 30 - 120°F)
± 0,4%
Less than 20 / 40 / 80 mA
± 0,3%
ATION & DIMENSIONS 500A: 46 x 120 x 54 mm 1000A: 68 x 168 x 75 mm 2000A: 68 x 168 x 100 mm
IP21
STANDARDS
EN 60335-1
EN-IEC 61000-6-1 EN-IEC 61000-6-2 EN-IEC 61000-6-3
EN 50498
Two cables with 1A fuse, for '+' connection and starter battery or midpoint connection
Optional (ASS000100000) The shunt and the electric cables do negatively influence the range of the Bluetooth signal. The resulting range of 10-15 meter is however satisfactory in most cases. The proximity of other electrically conducting elements, such as the metal chassis of a vehicle or seawater around the hull if a boat, may reduce the range of the Bluetooth signal to an unacceptable level. The solution in such a case is to add a VE.Direct Bluetooth Dongle (ASS030536011) to the system, and to switch off Bluetooth in the SmartShunt.



Measuring voltage of the starter battery





Measuring battery bank midpoint

